

WEST MIRA (WMI)

MARITIME INFO:

V-sat BRIDGE: +47 5288 4522

V-sat Medic/Admin: +47 5288 4501 /+47 5288 4503

Inmarsat – F TLF No: +870773940625

WMI WORKING CHANNEL: VHF Channel 69 / 06

Emergency VHF Ch 16

E-mail Bridge: dpo.wmira@seadrill.com

E-mail OIM: oim.wmira@seadrill.com


E-mail MSL: msl.wmira@seadrill.com

UHF Channels WMI:

Channels	RX	TX
Marine Ch 10	468.575000	468.575000
Marine Ch 09	468.550000	468.550000
Drilling Ch 05	467.550000	457.550000
Technical Ch 02	467.525000	457.525000

Cargo Connections:

Drillcutting / Waste	4"	Weco Male / Avery Hardoil
VBM	4"	Weco Male
Brine	4"	Weco Male
Base Oil / OBM	4"	Avery Hardoil
Diesel:	4"	Avery Hardoil
Drill Water	4"	Weco Male
Pot Water	4"	Weco Male
Cement	5"	Weco Male
Barite	5"	Weco Female



NB!

No bunker transfer to be started before bunkers delivery note are delivered on board the in hardcopy.

NWEA Guidelines to be followed by all vessels

entering West Mira safety zone. DP set-up checklist to be completed and reported to bridge prior to entering