





Platform Name:	Martin Linge B	
----------------	----------------	--


Contact Information			
Call sign:		E-mail:	
MMSI no:		Phone no:	
Position datum WGS 84 North, dms, Norne:	60°29'52.21"	VHF central control room:	
Position datum WGS 84 East, dms, Norne:	2°4'25.03"	UHF central control room:	

Contact Information cranes			
UHF crane 1		UHF crane 3	na
UHF crane 2	na	UHF crane 4	na



Zone color coding		
Color	Meaning	Reason
	Loading/offloading zone. Normal process with approval from the Central Control room	Crane coverage
	Entering this zone needs extra approval from Platform Manager in addition to Central Control room	na
	Exclusion zone. Entering this zone needs approved dispensation.	Bow: Risk of drift on collision. Weather from this direction. Stern: Risk of bow to stern collision due to heading. Also: Vessel operations in these areas should normally not be necessary

Other symbols/markings



180-degree obstacle free helicopter zone
 210-degree obstacle free helicopter zone
CAUTION: Turning radius. Platform is weathervaning and rotates within this circle. Sudden heading change could occur! See additional information for risks within this circle.

Platform specific information

Largest allowed vessel displacement for normal visit:
Lowest height from MSL to living quarter or lifeboats:
Lowest bridge height from MSL:

7500t
 na
 na

Displacement / Significant wave height -table for vessel operation on lo-ward side of platform


E = 21 MJ	
Vessel displacement [tonn]	H _{smax} [m] Broadside / stern impact
4000	5,5
4500	5,2
5000	4,9
5500	4,7
6000	4,5
6500	4,3
7000	4,1
7500	4,0
8000	3,9
8500	3,8
9000	3,7
9500	3,6
10000	3,5



Additional information

WARNING, Platform is weathervaning and has heading control. Sudden heading changes could occur:

- Zones marked on the map rotates with the platform heading.
- Be aware of risk of collision if loss of heading control when a vessel is inside the turning radius.
- The consequence of a ship collision with the platform ship side could be severe. Visiting vessels inside the turning radius must therefore use the following approach and keep the heading parallel to platform at all times:



Owner: Marine Technology Department Equinor

Rev. No	Date	Name
0	25.02.2020	moksh